

# Pallas HS1200 Fuji Fujicascope M2



## Instructions how to replace the belts (English)

Last updated: March 25, 2013 by Edwin van Eck.

### Required:

- motor belt (big), top belt (small)
- Pallas HS1200: order via: <http://shop.van-eck.net/snaren/pallas/p-1a/>
- Fuji Fujica M2: order via [shop.van-eck.net/BT-0004B--snaren.html](http://shop.van-eck.net/BT-0004B--snaren.html)
- Screwdriver Philips
- Patience



Replacing the belts takes approximately 1-2 hours.

### Instructions:

1. Open the projector on the backside.
2. Remove the old belts. Sometimes these are dissolved. The old gunk can be removed using thinner or alcohol.
3. Disconnect the transformer separately by 2 of the 4 screws, so that what is right can be shifted to its left space.
4. Loosen the 2 screws on the left of the transformer separately. This brings the axle and makes room for strings underneath to catch.
5. Remove the top axis (4 screws and spring).
6. Place the top belt. First lay the belt around the middle axis on the right side. Then lay it round the upper axis.
7. Attach the upper axis back (4 screws and spring). The top belt is now in place.
8. Place the engine belt
9. Make the centre axis (next to the transformer) with 2 screws
10. Attach the transformer again
11. Remove any grease residue on the strings by alcohol 96%
12. Put the cover on the back
13. Test the projector

